PAPER • OPEN ACCESS

Non-isothermal Dehydration Kinetics of Potassium Citrate Monohydrate

To cite this article: Xiaofang Wangy et al 2019 IOP Conf. Ser.: Mater. Sci. Eng. 490 022047

View the article online for updates and enhancements.

You may also like

- <u>Optical non-linearities by Z-scan</u> measurements, thermal characterization of single crystal: 8-hydroxyquinolinium 3carboxy-4-hydroxy benzene sulfonate monohydrate

R. Bhuvanesawri, M. Divya Bharathi and K. Sakthi Murugesan

- Growth of L-asparagine monohydrate and its structural, optical, mechanical, thermal and electrical studies for nonlinear optical applications

Apurva Gupta, Raseel Rahman M K, R O M U Jauhar et al.

- <u>Properties of Trifluoromethanesulfonic</u> <u>Acid Monohydrate Pertinent to Its Use as</u> <u>a Fuel Cell Electrolyte</u> T. Sarada, R. D. Granata and R. T. Foley





DISCOVER how sustainability intersects with electrochemistry & solid state science research



This content was downloaded from IP address 18.221.98.71 on 05/05/2024 at 20:47

IOP Publishing

Non-isothermal Dehydration Kinetics of Potassium Citrate **Monohydrate**

Xiaofang Wang*, Jun Dong, Songlin Fan, Fang Han, Yu Wang

Petroleum Engineering Research Institute of Petrochina Dagang Oilfield, Tianjin, China Corresponding author e-mail: wangxiaofang0626@163.com

Abstract: The dehydration kinetic of potassium citrate monohydrate has been investigated by TG-DTG. The kinetic parameters of activation energy and pre-exponential factor were calculated using the methods of FWO and KAS. The results show that the kinetic parameters calculated by two methods were consistent. Meanwhile, the most probable kinetic function was acquires by means of the Malek method. The thermodynamic functions of the dehydration process are then calculated according to the transition theory, which indicate that the dehydration process of potassium citrate monohydrate is endothermic and non-spontaneous.

1. Introduction

Potassium citrate is a potassium salt of citric acid, which is widely used in several fields^[1-4]. For example, potassium citrate is used in food industry as a food additive to regulate acidity, and used in medicine industry to control kidney stones derived^[5], etc.

There are some recently published work about the dehydration of some other types of compounds^[6]. The kinetic parameters of the dehydration step can be evaluated using non-mechanistic equations, such as. Free-man and Carroll^[7], Flynn-Wall-Ozawa Kissinger-Akahira-Sunose equations, etc. However, the dehydration mechanism can not be obtained by the methods above. However, the dehydration mechanism is significant for controlling the stability of hydrate.

In this paper, the dehydration behavior of potassium citrate monohydrate was investigated by the non-isothermal kinetic method using TG-DTG data. The kinetic parameters of A and E were determined according to the methods of FWO and KAS. Meanwhile, the most probable kinetic function is determined by the Malek method. In addition, the thermodynamic function ($\Delta S^{\neq}, \Delta H^{\neq}$ and ΔG^{*}) for the dehydration process of potassium citrate monohydrate were determined.

2. Theory

2.1. Non-isothermal kinetic analysis

On the basis of the thermogravimetric curves, the kinetic parameters (E and A) were determined using many methods. The methods of FWO and KAS were generally used to determined E of the dehydration process.

Content from this work may be used under the terms of the Creative Commons Attribution 3.0 licence. Any further distribution of this work must maintain attribution to the author(s) and the title of the work, journal citation and DOI. Published under licence by IOP Publishing Ltd 1

FWO equation:

$$\lg \beta = \ln \left(\frac{AE_{\alpha}}{RG(\alpha)} \right) - 2.315 - 0.4567 \left(\frac{E_{\alpha}}{RT} \right)$$
(1)

KAS equation:

$$\ln\left(\frac{\beta}{T^2}\right)_{\alpha} = \ln\left(\frac{AE}{G(\alpha)R}\right) - \frac{E_{\alpha}}{RT}$$
(2)

Malek method

The malek method equation:

$$y(\alpha) = \frac{f(\alpha).G(\alpha)}{f(0.5).G(0.5)}$$
(3)

and

$$y(\alpha) = \left(\frac{T}{T_{0.5}}\right)^2 \frac{\left(\frac{\mathrm{d}\alpha}{\mathrm{d}t}\right)}{\left(\frac{\mathrm{d}\alpha}{\mathrm{d}t}\right)_{0.5}} \tag{4}$$

The calibration curve can be obtained by equation (3), and the experiment curve can be obtained by equation (4). If the two curves can be consistent, the $G(\alpha)$ and $f(\alpha)$ is the most probable kinetic function.

2.2. Thermodynamic function

The thermodynamic function can be estimated by the equation (5) as following:

$$k_{\rm exp} = \chi K^{\star} \frac{k_{\rm B}T}{h} \tag{5}$$

Where k^{\neq} is the equilibrium constant. \mathcal{X} is the transmission coefficient. For the simple reaction, \mathcal{X} is approximately 1 unit? $k_{\rm B}$ and h are the Boltzmann and Planck constants, respectively. The ΔS^{\neq} , ΔH^{\neq} and ΔG^{\neq} can be calculated at T=Tp by the equations (6), (7) and (8).

$$\Delta S^{*} = R \ln \left(\frac{Ah}{\chi e k_{B} T_{p}} \right)$$
(6)

$$\Delta H^{\neq} = E^{\neq} - RT_{p} \tag{7}$$

$$\Delta G^{\neq} = \Delta H^{\neq} - T_{p} \Delta S^{\neq} \tag{8}$$

Where e is the Neper number (e=2.7183), Tp is the peak temperature of DTG curve.

3. Experimental apparatus and methods

3.1 Chemicals

Potassium citrate monohydrate was purchased from Tianjin tianzhi chemical Co. Ltd. The purity is above 99.5 %. The material was analyzed by the PXRD, and shows in the Figure 1.



Figure 1. PXRD pattern of potassium citrate monohydrate

3.2. Non-isothermal dehydration kinetic analysis

A thermal gravimetric analyzer was used to investigate the mass loss of water in potassium citrate monohydrate in the course of heating. Potassium citrate monohydrate were heated in an open aluminum pan from 30 to 800 $^{\circ}$ C at 2 $^{\circ}$ C/min under a nitrogen purge.

4. Results and discussions

4.1. The dehydration process of potassium citrate monohydrate

The dehydration process of potassium citrate monohydrate was analyzed by TG, and the TG-DTG curves are presented in Figure 2. The result shows that there is one DTG maxima peak at the temperature of 214.6 °C, which show that the dehydration process of potassium citrate monohydrate could be a single-step mechanism. The TG result suggests that mass loss in dehydration process is about 5.78%, almost 1 mol water.



Figure 2. TG-DTG curves of dehydration for potassium citrate monohydrate The thermal dehydration process may be represented by the following equation:

$$K_3C_6H_5O_7H_2O \xrightarrow{214.6^{\circ}C} K_3C_6H_5O_7 + H_2O \tag{9}$$

4.2 Kinetic studies

4.2.1. Determination of the most probable kinetic function of the dehydration process for potassium citrate monohydrate. The Malek method was widely used to obtain the most probable kinetic function. According to 21 frequently used kinetic functions in both differential and integral forms^[6], the calibration and experiment curve of dehydration process for potassium citrate monohydrate can be obtained using equations (3) and (4). The results show that the calibration curve is consistent with the experiment curve when the Malek method was carried out by No.18 as the most probable kinetic function (Figure 3). So the kinetic function No.18, Reaction order (n=2), is the most probable kinetic function is



Figure 3. The experiment and calibration curves of dehydration for potassium citrate monohydrate ●: experiment curve; ○ calibration curve.

4.2.2. Calculation of the kinetic parameters by isoconversionl method. The isoconversional method was widely used to determine the basic data of T and α , which were collected from the TG curve of the dehydration step for potassium citrate monohydrate at various heating rate are listed in Table 1. The plots of $\lg\beta$ versus 1/T (FWO) and $\ln(\beta/T^2)$ vs 1/T at different α can be obtained by least-square method by the equations (1) and (2), respectively(Figure 4 and Figure 5). The *E* and *A* can be obtained from the slopes and intercept of the straight lines in the α range from 0.2 to 0.8, and list in Table 2. As shown in Table 3, the *E* and *A* values calculated from two methods show a consistency. The calculated *E* and *A* values change with the different of α . However, the relative error of the *E* from the methods FWO and KAS is lower than 10%, which indicated that the dehydration process of potassium citrate monohydrate could be a single-step mechanism. This result is agree with the result of DTG analysis.

4.2.3. Determination of the thermodynamic functions. According to equations (6), (7) and (8), the ΔH^{\neq} , ΔS^{\neq} and ΔG^{\neq} values can be calculated. The values of ΔH^{\neq} , ΔS^{\neq} and ΔG^{\neq} from FWO are 112.5 J/K.mol, -125.3 kJ/mol and 176.1 kJ/mol, while those from KAS are 110.0 J/K.mol, -136.6 kJ/mol and 179.3 kJ/mol, respectively. The ΔS^{\neq} value means that the dehydration step is a "slow" stage. The positive ΔH^{\neq} and ΔG^{\neq} values mean that they are related to the introduction of heat and they are non-spontaneous process.

α	Temperature at different heating rate $(\beta/K.min^{-1})/K$					
	β=2	<i>β</i> =5	$\beta=10$	<i>β</i> =15		
0.2	207.1	222.13	235.61	241.39		
0.3	209.79	225.28	238.13	244.08		
0.4	211.87	227.59	239.96	246.23		
0.5	213.69	229.72	241.83	247.87		
0.6	215.45	231.78	243.43	249.69		
0.7	217.29	233.89	245.22	251.45		
0.8	219.43	236.29	247.15	253.99		

 Table 1. The temperature at various isoconversion at different heating rate for dehydration process of potassium citrate







Figure 5. KAS plots of dehydration process for potassium citrate monohydrate. •: α =0.2; •: α =0.3; **\Lambda**: α =0.4; $\triangle:\alpha$ =0.5; •: α =0.6; $\diamond:\alpha$ =0.7; **\Lambda**: α =0.8.

5. Conclusion

Dehydration Kinetics of Potassium Citrate Monohydrate was investigated by non-isothermal method based on the TG data. It is found that potassium citrate monohydrate exhibits one dehydration step:

$$K_{3}C_{6}H_{5}O_{7}.H_{2}O \xrightarrow{214.6^{\circ}C} K_{3}C_{6}H_{5}O_{7} + H_{2}O$$
(10)

Based on the data of TG at heating rate of 2 K/min, the most probable kinetic function was obtained using Malek method, the result shows that the kinetic function No.18, Reaction order (n=2), is the most probable kinetic function for dehydration process of potassium citrate monohydrate and the kinetic function is $f(\alpha) = (1-\alpha)^2$ and $G(\alpha) = (1-\alpha)^{-1} - 1$. The calculated values of *E* and *A* using FWO and KAS methods are 116.73 kJ/mol, 8.2×10^6 s⁻¹ and 114.21 kJ/mol, 2.1×10^6 s⁻¹.

On the basis of *E*, *A* and the most probable kinetic function, the thermodynamic function(ΔH^{\neq} , ΔS^{\neq} and ΔG^{\neq}) was calculated. The values of ΔH^{\neq} , ΔS^{\neq} and ΔG^{\neq} are 112.5 J/K.mol, -125.3 kJ/mol, 176.1 kJ/mol(from FWO), and 110.0 J/K.mol, -136.6 kJ/mol, 179.3 kJ/mol(from KAS), respectively. The results show that the dehydration process of potassium citreate monohydrate is a endothermic and non-spontaneous process.

		FWO						
α	Slope	E/(kJ/mol)	Intercept	A/S^{-1}	\mathbb{R}^2			
0.2	-6187.96	112.65	13.18	9.9×10^{5}	0.9971			
0.3	-6286.08	114.43	13.31	1.9×10^{6}	0.9979			
0.4	-6357.98	115.74	13.40	3.2×10^{6}	0.9985			
0.5	-6430.36	117.06	13.50	5.2×10^{6}	0.9974			
0.6	-6488.14	118.11	13.57	8.3×10^{6}	0.9970			
0.7	-6554.46	119.32	13.65	1.4×10^{7}	0.9957			
0.8	-6580.29	119.79	13.65	2.4×10^{7}	0.9956			
AV.		116.73		8.2×10^{6}				
α -	_	KAS						
	Slope	E/(kJ/mol)	Intercept	A/S^{-1}	R^2			
0.2	-13254.71	110.20	15.94	1.6×10^{5}	0.9967			
0.3	-13475.40	112.03	16.23	3.5×10^{5}	0.9976			
0.4	-13636.83	113.37	16.44	6.6×10^5	0.9983			
0.5	-13800.08	114.73	16.64	1.2×10^{6}	0.9970			
0.6	-13929.67	115.81	16.79	2.1×10^{6}	0.9966			
0.7	-14078.85	117.05	16.98	3.9×10^{6}	0.9952			
0.8	-14133.78	117,50	16.95	6.5×10^{6}	0.9951			
AV.		114.21		2.1×10^{6}				

Table 2. The E and R^2 caculated by the methods of FWO and KAS for the dehydration process of potassium citrate monohydrate

References

[1] Khankari, R.K., D.J. Grant. Pharmaceutical hydrates. Thermochimica Acta. 1995; 248: 61-79.

[2] Bechtloff, B., S. Nordhoff, J. Ulrich. Pseudopolymorphs in industrial use. Crystal Research and Technology. 2001; 36(12): 1315-1328.

[3] Surowiec, J.,R. Bogoczek. Studies on the thermal stability of the perfluorinated cation-exchange membrane Nafion-417. Journal of Thermal Analysis and Calorimetry. 1988; 33(4): 1097-1102.

[4] Tanner, G.A. Potassium citrate/citric acid intake improves renal function in rats with polycystic kidney disease. Journal of the American Society of Nephrology. 1998; 9(7): 1242-1248.

[5] Koren, H., *Environmental health and safety*1974: Pergamon Press Ltd., Headington Hill Hall, Oxford.

[6] Foppoli, A. Dehydration kinetics of theophylline-7-acetic acid monohydrate. Journal of Thermal Analysis and Calorimetry. 2010; 99(2): 649-654.